


## Greasecutter Plus

Heavy duty degreaser and cleaner



- Concentrate ready-to-use formula for cleaning grills and ovens
- Removes baked-on oven and grill residues




# Greasecutter Plus

## Heavy duty degreaser and cleaner

### Product Description

GREASECUTTER PLUS is a highly effective ready-to-use grill and oven cleaner. GREASECUTTER PLUS can be used in grill units, deep fryers, tilting-type frying pans, baking ovens and combi-steamers. Full strength cleaning action destroys the toughest grease and deposits.

### Use Instruction



1. Always wear protective gloves and safety glasses. Use heat-resistant gloves if necessary.
2. Ensure the oven temperature is no more than 50° C.
3. Spray interior with GREASECUTTER PLUS. Avoid fan area.
4. Close oven door for 10 - 15 minutes and allow product to work.
5. Open door, wipe interior with wet cloth or scrub pad.
6. Rinse with plenty of clean water to remove all residue and allow to air dry, or dry with paper towels.

### pH-Value

(undiluted solution)

7	8	9	10	11	12	13	14
---	---	---	----	----	----	----	----

### Safety

**For professional use only.**

Keep out of reach of children.

Wear suitable protecting clothing, gloves and eye / face protection when handling the product.

Do not mix with anything but water.

For further information and safety instructions see product label and safety data sheet.

### Pack Size

4x5L per outer case

### Storage conditions

Keep container tightly closed.

Keep only in the original container.

Store between 10 and 40°C.



**Ecolab GmbH & Co. OHG**  
P.O. Box 13 04 06  
D-40554 Düsseldorf  
Phone ++49 211 98 93-0  
Fax ++49 211 98 93-384

**Ecolab Ltd.**  
David Murray John Building  
Swindon, Wiltshire SN1 1NH (GB)  
Phone ++44 1 793 51 12 21  
Fax ++44 1 793 61 85 52

**Ecolab Ltd.**  
La Vallee House,  
Upper Dargle Road  
IRL - Bray, Co. Wicklow  
Phone ++353 / 1 / 276 3500

[www.ecolab.com](http://www.ecolab.com)